

# DALTEX BASE4BOUND

## PATHWAYS AND PATIOS – APPLICATION

### Product Overview:

DALTEX BASE4BOUND is an eco-friendly, durable base, specifically designed for use with resin bound, it is a superior alternative to conventional open-grade Tarmac and no-fines concrete bases commonly used in resin-bound systems

### Key Features:

Utilises repurposed aggregates and a superior polyurethane high quality binder.

### Tools required:

- Forced Action Mixer
- Paddle Mixer/Whisk
- Roller
- Wheelbarrow or Buckets
- Trowel
- Spazzle/Rake/Spreader
- Cutting Equipment

### Sub-Base Requirements:

Permeable Installation

#### 1. Sub-Base Composition:

- A depth of 125-225mm compacted MOT Type 3 aggregate. Depth would be decided depending on Sub Soil composition.
- Laid on a non-woven geotextile membrane to separate the sub-base and sub-soil.

#### 2. Capping Layer:

- Use a 5-10mm clean aggregate as a capping layer for stability and uniform levels.

### Installation Instructions:

#### Step 1: Sub-Base Preparation

Ensure the prepared sub-base is:

- Compacted in layers for the best results, this should be done using a whacker plate or roller.
- Uniform in level.

#### Step 2: Structural Reinforcement Mesh (SRM)

1. Roll out the SRM and cut it to the required size.
2. Ensure the SRM is tight to the edges
3. SRM Mesh can be overlapped up to 15 centimetres.  
This will help to avoid any waves being created where the mesh joins together.

### Installation Instructions (continued):

#### Step 3: Mixing Process

1. **Prepare the Aggregates:** Before turning on the forced action mixer, add two bags of 4-10mm aggregate into the drum.
2. **Mix the Resin:** In a separate container, pour Part B into Part A and blend the two components using a paddle mixer for 90 seconds until the mixture is fully homogenous.
3. **Start the Mixer:** Once the resin is thoroughly mixed, turn on the forced action mixer.
4. **Add Remaining Aggregates:** Add the next two bags of 4-10mm aggregate while the mixer is running.
5. **Incorporate the Resin:** Immediately after adding the final two bags of aggregate, pour the fully mixed resin into the forced action mixer. Ensure all resin is scraped from the container to prevent material waste.
6. Once the resin has been added to the forced action mixer, add DALTEX Binding Quartz.
7. **Final Mixing:** Allow the mixer to blend the resin and aggregate for 120 seconds, ensuring a consistent and even distribution throughout the mixture and uniform levels.

#### Step 4: Application

1. Discharge the mix into a plastic-lined wheelbarrow or similar.
2. Transport to the working area and tip onto the SRM.
  - Take care not to dislodge or create waves in the mesh.
3. Level the base mix using a spazzle or similar tool to ensure full SRM coverage.
  - Ensure the mix reaches the correct depth. DALTEX BASE4BOUND being installed for pedestrian use should be installed at 15mm.

#### Step 5: Curing

- Cordon off the area and allow the system to cure fully.
- Full Chemical cure within 7 days.